


MODE KNOB 1 KNOB 2 BUTTON KNOB 1 KNOB 2 TUNE VOLUME POWER 9VDC -G+ LINE OUT

- Vibrato Synth
 - Harmonic Sweeper
 - 2-Octave Arpeggiator
 - Octave Cascade
 - Mono FM Synth
 - FM Arpeggiator
 - Mono Glider
- Depth
 - Rate
 - Rate
 - Rate
 - Harmonicity
 - Rate
 - Detune
- Rate
 - Envelope
 - Envelope
 - Decay
 - Index/Envelope
 - Index/Envelope
 - Glide
- Waveform
 - Waveform
 - Waveform
 - Waveform
 - Octave Shift
 - Octave Shift
 - Waveform



POCKET PIANO GR™
 CRITTER & GUITARI™
www.critterandguitari.com